



A Program for  
MS **W**indows  
for  
(**L**ife **I**nformation using **F**inite **E**lements)

**Lecture-Kit** **w**in **l**ife **MULTIAXIAL**  
**for Universities**  
**(for Research and Tuition only)**

Copyright: Steinbeis Transfer Center  
„New Technologies in Traffic Engineering“  
Prittwitzstr. 10  
89075 Ulm  
Tel.: +49 7325/3306  
Fax.: +49 7325/4992

Version 3.0  
Ulm, den 9.6.2009

*c:\ \hi2uni\_mux\_30\_09\_06\_2009.doc*



Lecture-Kit winLIFE MULTIAXIAL for Universities  
(for Research and Tuition purposes only)

## I. The Lecture-Kit

In order to work with the Lecture-Kit winLIFE MULTIAXIAL it is necessary that you already have the Lecture-Kit winLIFE BASIC.

**Table 1: Scope of the Lecture-Kit winLIFE BASIC**

	Full version without limitations	Student version (limited version)
winLIFE BASIC	1	10
winLIFE MULTIAXIAL	Not available	Not available
Hardlock	1 for single user	1 for Server

**Table 2: Scope of the Lecture-Kit winLIFE MULTIAXIAL**

	Full version without limitations	Student version (limited version)
winLIFE BASIC	winLIFE BASIC must already be available	winLIFE BASIC must already be available
winLIFE MULTIAXIAL	1	10
Hardlock	1 for single user	1 for Server

Therefore, if you purchase the Lecture Kit winLIFE BASIC AND the Lecture-Kit winLIFE MULTIAXIAL you will have:

1 full version of winLIFE BASIC and winLIFE MULTIAXIAL on 1 hardlock.

10 limited student versions of winLIFE BASIC and winLIFE MULTIAXIAL, which can only be used within a network with a server hardlock.



## II. Included in the Delivery:

It is necessary that you already have the Lecture Kit **winLIFE BASIC**.

You will be supplied with:

**winLIFE MULTIAXIAL** (without limitations: Lecturer Version) secured by the **USB Hardlock** which was already delivered with **winLIFE BASIC**. You will only need a new password. The program can be supplied on a CD or download as required and includes documentation in English and German.

10 versions with limited function (student versions) for server installation onto a network (Novell or Windows). You use the same **Server Hardlock** which was already supplied with the Lecture-Kit **winLIFE BASIC**. A new password will be provided.

## III. Installation

**Please read the installation notes.**

The **winLIFE** program is to be installed by the purchaser in the university network. The server-dongle supplied for this purpose only allows that the purchased number of versions (10) can be used simultaneously. The full version (lecturer version) is supplied with a separate hardlock so that it can be used independently from the server.

The seller will provide telephone support for the installation if necessary.

## IV. Limitations of the Student Version

The limitations for **winLIFE BASIC** continue to apply here. In addition, there are also the following limitations for **winLIFE MULTIAXIAL**:

- A maximum of 10 different load-time-histories (winLIFE Multiaxial) can be used at the same time.
- Time scaling is not possible.

## V. Guarantee, Hotline and Maintenance

We offer maintenance for the full lecturer version at the same price as we charge customers from industry. Updates which are supplied free of charge for customers with a maintenance contract, automatically include updates for the student versions.

There is no hotline for the student version. We can only support you with problems that occur when you install the program. We assume that the lecturer with the full version will be able to help the users of the student versions.